
Host Board
System 2
Host Board 10
Single Width
Transceiver
70-2
Connector 90
Slot 80
Bezel 20
Bezel Opening 30
Dual Width Transceiver 60-2
Bezel-Opening Insert 40
Dual Width
Transceiver 60-1
Bezel-Opening
Insert 50
Single Width
Transceiver
70-1

Figure 1


Bezel 20
Openings for transceivers
Bezel-opening insert 54
Bezel-opening insert 52
Bezel-opening insert 50
Bezel-opening insert 40

Figure 2A

TO2201' 5665001



Figure 2B

T0220T' 5669E00T



Figure 2C



Figure 2D

TO2201 5665201



Figure 2E

T02207 SOOSE00T



Figure 3A

10220T 5669E0T



Figure 3B



Figure 4

1003609S.102201

T02207 S6693007



Figure 5

TO2807 S6696001



Figure 6

T0220T' 5665200T



Figure 7



Figure 8